

Dip-switch quick configuration capabilities Element Controller
(Art. REF: 062.8610.--)

V1.0 09/2017



Please follow the instructions as described in the Element Controller manual.
 This is a reference list; for latest updates check our website: <http://setup-ec.reynaers.com>

Our sliding window configuration symbols

<i>symbol</i>	<i>explanation</i>
Q / P	Fixed vent / pocket integration
X	Motorized vent
O	Non-motorized free moving vent
-	Middle closing
v	Corner closing
(X)	Motorized vent moving in opposite direction

Dipswitch settings are a binary code from de ref. with 1-8 order from left to right and with **0** as switch placed to bottom position and **1** is the switch placed in up position.

Configuration	Dipswitches (1-8)	Ref.
XQ	00000001	1
XXQ	00000010	2
XXXP	00000011	3
XXXXP	00000100	4
QX-XQ	00000101	5
QXX-XQ	00000110	6
QXX-XXQ	00000111	7
PXXX-XQ	00001000	8
PXXX-XXQ	00001001	9
PXXX-XXXP	00001010	10
QXvXQ	00001011	11
QXvXXQ	00001100	12
QXvXXXP	00001101	13
QXXvXQ	00001110	14
QXXvXXQ	00001111	15

Configuration	Dipswitches (1-8)	Ref.
XOQ	00100011	35
XOOP	00100100	36
QOX-XQ	00100101	37
QOX-XOQ	00100110	38
POOX-XQ	00100111	39
POOX-XOQ	00101000	40
POOX-XOOP	00101001	41
QXvXOQ	00101010	42
QXvXOOP	00101011	43
QOXvXQ	00101100	44
QOXvXOQ	00101101	45
QOXvXOOP	00101110	46
POOXvXQ	00101111	47
POOXvXOQ	00110000	48
POOXvXOOP	00110001	49

QXXvXXXP	00010000	16
PXXvXQ	00010001	17
PXXvXXQ	00010010	18
PXXvXXXP	00010011	19
X(X)	00010100	20
XX(X)	00010101	21
XX(XX)	00010110	22
QXvX(X)	00010111	23
QXvX(XX)	00011000	24
QXvXX(X)	00011001	25
QXvXX(XX)	00011010	26
QXXvX(X)	00011011	27
QXXvX(XX)	00011100	28
QXXvXX(X)	00011101	29
QXXvXX(XX)	00011110	30
PXXvX(X)	00011111	31
PXXvX(XX)	00100000	32
PXXvXX(X)	00100001	33
PXXvXX(XX)	00100010	34

QOXvX(X)	00110010	50
QOXvX(XX)	00110011	51
QOXvXX(X)	00110100	52
QOXvXX(XX)	00110101	53
POOXvX(X)	00110110	54
POOXvX(XX)	00110111	55
POOXvXX(X)	00111000	56
POOXvXX(XX)	00111001	57

